

Changes: To minimize exposure of dust to welding sparks.  
To minimize electrical interference from welders with the CNC electronics.

- 1) Move CNC to “bottom” wall
- 2) Change the wall position to allow space for CNC.
- 3) Open former CNC area and move in Member Storage Racks (for non-combustible materials).
- 4) Wall off former CNC area to minimize dust moving from the wood shop into the Welding shop.



