

Changes: To minimize exposure of dust & paint fumes to welding sparks

1) Move CNC to “bottom” wall, and change the wall position to allow space.

2) Move the Dust Collector out of the Paint Booth room.

3) Move Paint Booth to former CNC area.

4) Wall off former CNC area with “dust travel prevention height” walls including light-weight doors fitted with high efficiency disposable furnace filters, to minimize dust travel.

Walling off the new Paint Booth area, with booth exhaust to the outside, will minimize dust moving from the wood shop into the Welding shop. Filters on the doors to the painting area will minimize the dust being drawn into the Paint Booth when the booth exhaust is running.

